






| Part No                                 | Inductance (nH) | Tolerance | Test Frequency (Hz) |  | Temperature Rise Current Max. (mA) | DC Resistance Max. (Ω) | SRF Min. (MHz) |
|-----------------------------------------|-----------------|-----------|---------------------|--|------------------------------------|------------------------|----------------|
| <input type="checkbox"/>                |                 |           |                     |  |                                    |                        |                |
| WCIV2520HF-R10 <input type="checkbox"/> |                 |           |                     |  |                                    |                        |                |
| WCIV2520HF-R12 <input type="checkbox"/> |                 |           |                     |  |                                    |                        |                |
| WCIV2520HF-R15 <input type="checkbox"/> |                 |           |                     |  |                                    |                        |                |
| WCIV2520HF-R18 <input type="checkbox"/> |                 |           |                     |  |                                    |                        |                |
| WCIV2520HF-R22 <input type="checkbox"/> |                 |           |                     |  |                                    |                        |                |
| WCIV2520HF-R27 <input type="checkbox"/> |                 |           |                     |  |                                    |                        |                |
| WCIV2520HF-R33 <input type="checkbox"/> |                 |           |                     |  |                                    |                        |                |
| WCIV2520HF-R39 <input type="checkbox"/> |                 |           |                     |  |                                    |                        |                |
| WCIV2520HF-R47 <input type="checkbox"/> |                 |           |                     |  |                                    |                        |                |
| WCIV2520HF-R56 <input type="checkbox"/> |                 |           |                     |  |                                    |                        |                |

Inductance Tolerance: G=±2% , J=±5%



IMPEDANCE(Ω)

